

WEEK 2

Experiment # 6

Remembering Long Lists Using EEPROM

EEPROM stands for Electrically Erasable Programmable Read Only Memory. It is a small black chip on the BASIC Stamp II module labeled “24LC16B”. It is used to store the program and data temporarily. When you don’t need the program / data inside the EEPROM, you can replace it with another one. EEPROM can accept a finite number of write cycles, around 10 million writes. The EEPROM chip on BASIC Stamp II (24LC16B) can hold up to 2048 bytes (2 kB) of information.

<code>goto main</code>	<code>' Send program back to the main</code>
<code>backward:</code>	<code>' Backward routine</code>
<code>for pulse_count = 1 to 75</code>	<code>' Sends 75 backward pulses</code>
<code>pulsout 12, 1000</code>	<code>' 2.0 ms pulse to right servo</code>
<code>pulsout 13, 500</code>	<code>' 1.0 ms pulse to left servo</code>
<code>pause 20</code>	<code>' Pause for 20 ms</code>
<code>next</code>	
<code>goto main</code>	<code>' Send program back to the main</code>
<code>left_turn:</code>	<code>' Left turn routine</code>
<code>for pulse_count = 1 to 35</code>	<code>' Sends 35 left rotate pulses</code>
<code>pulsout 12, 500</code>	<code>' 1.0 ms pulse to right servo</code>
<code>pulsout 13, 500</code>	<code>' 1.0 ms pulse to left servo</code>
<code>pause 20</code>	<code>' Pause for 20 ms</code>
<code>next</code>	
<code>goto main</code>	<code>' Send program back to the main</code>
<code>right_turn:</code>	<code>' Right turn routine</code>
<code>for pulse_count = 1 to 35</code>	<code>' Sends 35 right rotate pulses</code>
<code>pulsout 12, 1000</code>	<code>' 2.0 ms pulse to right servo</code>
<code>pulsout 13, 1000</code>	<code>' 2.0 ms pulse to left servo</code>
<code>pause 20</code>	<code>' Pause for 20 ms</code>
<code>next</code>	
<code>goto main</code>	<code>' Send program back to the main</code>

Program Explanation:

Both the “*EE_address*” and “*instruction*” variables are in byte, which means that they can store numbers between 0 and 255. The “*EE_address*” variable is used for specifying the EEPROM address to read a direction instruction from EEPROM. The “*instruction*” variable is used to store the instruction character read from EEPROM. The next declaration (“*data*”) is the actual data to be stored in EEPROM. This data is stored as a string of characters.

The *main* routine first reads EEPROM address 0, and stores it in the *instruction* variable. Then, *EE_address* is incremented so that the next read cycle will look at address 1. A series of *if ... then* statements is used to decide what to do based on the character retrieved from EEPROM and stored in the *instruction* variable. The *if ... then* statements check to see if it is one of four known instruction characters: “F”, “B”, “R”, and “L”. For example, if the character is an “R”, the first two *if ... then* statements are skipped because neither of them is true. Since the third *if ... then* statement is true, the program skips to the *right_turn* routine and executes it.

When the program gets into *goto main* command, it will execute the *main* routine, then the next EEPROM instruction is fetched and the instruction is checked by the four *if ... then* statements again. The process is repeated until the quit character “Q” is read from EEPROM. When “Q” is loaded into the *instruction* variable, it fails all four *if ... then* tests. So, the program does not go to any of the navigation routines. Instead, the program goes to the command that follows the series of *if ... then* statements, which is the *stop* command.

Save the program as “Prog2_5.bs2” and run it.

Your Boe-Bot should remain still and plays the tone for 2 seconds. Then it is moving with respect to the navigation direction data, which is moving forward, backward, turn a quarter turn to the left, moving forward, turn a quarter turn to the right, and then moving forward again and finally stops.

Task:

1. Try changing, adding, and deleting characters in the *data* directive. Remember that the last character in the *data* directive should always be a “Q”.
2. Try adding a second *data* directive. Remember to remove the “Q” from the end of the first *data* directive and add it to the end of the second. Otherwise, the program will execute only the commands in the first *data* directive.

Simplify Navigation with Subroutines

A subroutine is a segment of code that does a particular job. To make the subroutine do its job, a command is used in the main routine that “calls” the subroutine. The command for calling a subroutine is the *gosub* command, and it is similar to the *goto* command. A *goto* command tells the program to go to a label and then start executing instructions. The *gosub* command tells the program to go to a label and start executing instructions, but come back when finished. A subroutine is finished when the *return* command is encountered.

Activity:

Type the following codes onto the Stamp Editor.

```
' Program Listing 2.6, Subroutine Navigation.
' {$Stamp bs2}                                ' Stamp Directive

' -----Declarations -----
loop_count var word                            ' For ... next loop counter
right_width var word                          ' Variable stores right pulse width
left_width var word                           ' Variable stores left pulse width
pulse_count var word                          ' Used to set # of pulses delivered

' ----- Initialization -----
output 2                                       ' Set P2 as output pin
freqout 2, 2000, 3000                        ' Signal program is (re)starting
low 12                                        ' Set P12 and P13 to output-low
low 13

' ----- Main routine -----
main:
    forward:                                ' Forward routine
        pulse_count = 75                    ' Set pulse_count for 75 pulses
        right_width = 500                   ' Set right pulse width to 1.0 ms
        left_width = 1000                   ' Set left pulse width to 2.0 ms
        gosub pulses                        ' Call the pulses subroutine
        pause 500                           ' Pause for 0.5 s

    backward:                                ' Backward routine
        pulse_count = 75                    ' Set pulse_count for 75 pulses
        right_width = 1000                  ' Set right pulse width to 2.0 ms
        left_width = 500                    ' Set left pulse width to 1.0 ms
        gosub pulses                        ' Call the pulses subroutine
        pause 500                           ' Pause for 0.5 s

    stop                                    ' Stop executing commands until reset

' ----- Subroutines -----
pulses:                                       ' Pulses subroutine
    for loop_count=1 to pulse_count ' Use pulse_count for # of pulses
```

```
pulsout 12, right_width  ' Use right_width for right pulse width
pulsout 13, left_width   ' Use left_width for left pulse width
pause 20                  ' Pause 20 ms
next
return                    ' Return from subroutine
```

Program Explanation:

In the *forward* and *backward* routine, when it gets into *gosub pulses* command, it will jump to the *pulses* subroutine. The commands in the *pulses* subroutine are executed until the program gets to the *return* command. The *return* command sends the program back to the command just after *gosub pulses* command, which is *pause 500* in this case.

Save this program as “Prog2_6.bs2” and run it.

Your Boe-Bot should remain still and plays the tone for 2 seconds. Then it starts moving forward. Stops for about 0.5 second and then it should move backward and stops on its initial position.

Task:

1. Add routines to the main routine that set the values for a quarter of right turn and left turn. Save this program with the same name (“Prog2_6.bs2”) and run it.
2. Create a source code for one of the following movement patterns:

